



---

## VIRTUO VR: CASQUES VR COMPATIBLES ET CONFIGURATION SYSTÈME REQUISE




Tesy Software S.r.l. – Via E. Reginato, 3 – Treviso  
Assistance distributeurs Tél.: +39 0422 230004  
Assistance producteurs Tél.: +39 0422 230424  
[www.tesysoftware.com](http://www.tesysoftware.com)

# Liste de casques compatibles et configuration système demandée pour vivre l'expérience virtuelle réalisée avec **Virtuo VR**

## 1 – Oculus Quest 2

Lien pour l'achat:

<https://www.oculus.com/quest-2>



Ce casque est produit sans câble, toutefois pour son utilisation avec Virtuo il faut ajouter un câble de 3 mètres, avec la possibilité d'y attacher une rallonge optionnelle de 5 mètres (total 8 mètres)

Ci-dessous les liens pour l'achat des câbles:

Câble

[https://www.amazon.it/gp/product/B01MZIPYPY/ref=ppx\\_yo\\_dt\\_b\\_asin\\_title\\_o01\\_s00?ie=UTF8&psc=1](https://www.amazon.it/gp/product/B01MZIPYPY/ref=ppx_yo_dt_b_asin_title_o01_s00?ie=UTF8&psc=1)

Rallonge

[https://www.amazon.it/gp/product/B0179MXKU8/ref=ppx\\_yo\\_dt\\_b\\_asin\\_title\\_o02\\_s00?ie=UTF8&psc=1](https://www.amazon.it/gp/product/B0179MXKU8/ref=ppx_yo_dt_b_asin_title_o02_s00?ie=UTF8&psc=1)

## Configuration système demandée pour casque Oculus Quest 2

# SUPPORTED GPUS FOR OCULUS LINK

Bear in mind that if your card isn't listed as "Supported", we can't guarantee compatibility.

### NVIDIA GPU

NVIDIA TITAN Z	NOT CURRENTLY SUPPORTED
NVIDIA TITAN X	SUPPORTED
NVIDIA GEFORCE GTX 970	SUPPORTED
NVIDIA GEFORCE GTX 1060 DESKTOP, 3 GB	NOT CURRENTLY SUPPORTED
NVIDIA GEFORCE GTX 1060 DESKTOP, 6 GB	SUPPORTED
NVIDIA GEFORCE GTX 1060M	NOT CURRENTLY SUPPORTED
NVIDIA GEFORCE GTX 1070 (ALL)	SUPPORTED
NVIDIA GEFORCE GTX 1080 (ALL)	SUPPORTED
NVIDIA GEFORCE GTX 1650	NOT CURRENTLY SUPPORTED
NVIDIA GEFORCE GTX 1650 SUPER	SUPPORTED
NVIDIA GEFORCE GTX 1660	SUPPORTED
NVIDIA GEFORCE GTX 1660 TI	SUPPORTED
NVIDIA GEFORCE RTX 20-SERIES (ALL)	SUPPORTED

### AMD GPU

AMD 200 SERIES	NOT CURRENTLY SUPPORTED
AMD 300 SERIES	NOT CURRENTLY SUPPORTED
AMD 400 SERIES	SUPPORTED
AMD 500 SERIES	SUPPORTED
AMD 5000 SERIES	SUPPORTED
AMD VEGA SERIES	SUPPORTED

## 2 – HTC VIVE Pro

Lien pour l'achat:

<https://www.alternate.it/HTC/Vive-Pro-Full-Kit-Occhiali-VR/html/product/1442125?>



Le casque VR vient connecté à l'ordinateur avec un câble. Si l'on voulait rendre le casque VR sans-fil (sans câble) il existe l'option d'acheter un kit :

### HTC VIVE WIRELESS ADAPTER

<https://www.alternate.it/html/product/1488261/>

**ATTENTION: le dispositif PCI-E est nécessaire – il fonctionne seulement avec un ordinateur de bureau, il n'est pas possible de le relier à un ordinateur portable**



## Installation

Pour la préparation de l'espace virtuel et l'installation du programme, nous renvoyons à:

<https://www.youtube.com/watch?v=rv6nVPPDmEI&index=6&list=PLLnVNxirkBP-zqY1-imCFqv1cL4klFLXZ>

---

## Configuration conseillée et minimale pour HTC VIVE Pro

Component	Recommended system requirements	Minimum system requirements
<b>Processor</b>	Intel Core i5-4590/AMD FX 8350 equivalent or better	Intel Core i5-4590/AMD FX 8350 equivalent or better
<b>GPU</b>	NVIDIA GeForce GTX 1070/Quadro P5000 equivalent or better, AMD Radeon Vega 56 equivalent or better	NVIDIA GeForce GTX 970, AMD Radeon R9 290 equivalent or better
<b>Memory</b>	4 GB RAM or more	4 GB RAM or more
<b>Video output</b>	DisplayPort 1.2 or newer	DisplayPort 1.2 or newer
<b>USB port</b>	1x USB 3.0 or newer	1x USB 3.0 or newer
<b>Operating system</b>	Windows 10	Windows 7 SP1, Windows 8.1 or later, Windows 10

## Configuration minimale pour Htc Vive Wireless Adapter (optionnel)

<b>Computer Type:</b>	Desktop computer with available PCIe Slot
<b>Processor:</b>	Intel® Core i5-4590/AMD FX™ 8350 equivalent or better
<b>GPU:</b>	NVIDIA® GeForce® GTX 1060, AMD Radeon™ RX 480 equivalent or better
<b>Memory:</b>	4 GB RAM or more
<b>Operating system:</b>	<ul style="list-style-type: none"><li>• For VIVE Pro: 64-bit Windows® 10 or Windows® 7 SP1</li><li>• For VIVE: 64-bit Windows® 10 or Windows® 7 SP1</li></ul>